

GoMoG Service I

FRONT SUSPENSION

Check play in bushes

Clean bottom part – [check for rust](#) on kingpin (switch to [hardchromes](#))

Check bottom nyloc nut and base plate bolts or tightness

Check [one-shot](#) lube bolt – brush clean and lube the one shot union (with WD40) (p

Check [one shot](#) pipe (pre-2002)

Check the wing/side-light nuts for tightness

[Check wing stay](#) (replace them with your own if you have a post 2001 version)

Clear vent hole at bottom of top tube of slider (*yes there is one at the rear*)

Grease bushes according to year

[Change damper blade shims](#) – turn damper blades over – grease (pre-2008)

Check shocks for proper function. (*article needed!*)

Check front indicator lights [Electrical Index Section 11](#)

Check front parking lights [Electrical Index Section 11](#)

Check wing lights

Check Hazard Lights [Electrical Index Section 11](#)

Check Headlamp Alignment

Check horn (s)

Check bumper bolts, attachments and support bolts