

Driver seat (left hand)

|   |           |   |            |
|---|-----------|---|------------|
| • Left hand sidelights  | 1<br>7,5A | • Injection +   | 11<br>15A  |
| • Right hand sidelights<br>• Radio illumination   | 2<br>7,5A | • Direction lights<br>• Dashboard warning light unit (control lights) | 12<br>10A  |
| • Dashboard green light sidelight   | 3<br>15A  | • Heated windscreen   | 13<br>10A  |
| • Left hand low beam  | 4<br>7,5A | • Fan heater<br>• Dashboard instrument illumination                   | 14<br>15A  |
| • Right hand low beam   | 5<br>7,5A | • Wipers<br>• Windscreen washer                                       | 15<br>10A  |
| • Left hand high beam   | 6<br>10A  | • Rear stop light<br>• Rear reversing light                           | 16<br>7,5A |
| • Right hand high beam  | 7<br>10A  | • Horn  | 17<br>10A  |
| • Hazard<br>• Unit immobiliser<br>• Radio   | 8<br>10A  | • Injection pump or<br>• Injection or<br>• Unit immobiliser           | 18<br>20A  |
| • Water radiator fan relay<br>• Sidelight & Dashboard greenlight sidelight<br>• Map reading lamp<br>• Lighter | 9<br>15A  | • Injection pump or<br>• Injection or<br>• Unit immobiliser           | 19<br>15A  |
| • Water radiator fan (power)  | 10<br>30A | • Injection pump or<br>• Injection or<br>• Unit immobiliser           | 20<br>20A  |