

GoMoG SERVICE

COOLANT SYSTEM

Check rad hoses for correct firmness, cracks or rubbing

Check rad for leaks or rubbing

Check coolant level

Test coolant quality

Change coolant. Flush and change every two years

Check rad cap for leaks when hot

Test Coolant for electricity (very important for alloy engines and rads)

Check fan function and the direction the blades are turning Cooling Section 6

.