

THE GoMog SERVICE LIST



ENGINE AREA

DONE

Drain oil – replace oil filter – Fill up (All cars save Plus 8s see *below*)

Fill new oil filter - [replace old oil filter](#) - Drain & fill up. (Plus 8s only)

Replace spark plugs – check & adjust gap to engine's spec

[Examine old plugs for condition](#)

[Checking spark plug wires/leads & connectors](#)

Check heater valve cable

Check fan belt tension and wear [Note for later Plus 8s](#)

Check dynamo or alternator wiring

Check regulator and fuse box for corrosion (if applicable)

Check all engine mountings for bolt tightness and cracks in the rubber sections

Check slave cylinder leaks and clutch master cylinder fluid level (if hydraulic) (change both fluid every two

years)	
Check, lub and adjust clutch linkage and cable	
Check, lub and adjust accelerator linkage and cable	
<u>Check function of Inertia Switch</u>	
<u>Check engine earth (s) VERY carefully (both sides of the strap) for broken strands or a bad contact</u>	
Clean and dielectric grease earth strap(s) contact (s) on chassis	