



# Roadster. Fuses

Keep Alive Fuse 5A 1		20 Not Used	
Fuel System Relay 20A 2		19 Not Used	
Instrument Panel 10A 3		18 Not Used	
Alternator 10A 4		17 Not Used	
Start Relay 20A 5		16 VPWR 5 5A	5A: MEE0680
Air Con Relay 10A 6		15 VPWR 4 15A	7.5: MEE0681
Cooling Fan Relay 30A 7		14 VPWR 3 5A	10A: MEE0682
Power Control Module Relay 30A 8		13 VPWR 2 15 A	15: MEE0683
OBD 15A 9		12 PCM VPWR 15A	20A: MEE0684
Instrument Panel/Pats/Mode Select 5A 10		11 PCM/FUEL SYSTEM RELAY DRIVE 5A	40A: MEE0701
			50A: MEE07010
			80A: MEE07020
Hazards 10A 1		20 N/S Side Lights & No. Dash Illum 7.5A	
Side Light Switch 10A 2		19 O/S Side Lights & Dash Illum 7.5A	
Power Skt/Map Light 15A 3		18 Dipped Beam N/S 7.5A	
Radio/Courtesy Light/ Clock 10A 4		17 Dipped Beam O/S 7.5A	
Body Control Unit 2A 5		16 Main Beam N/S 10A	
Radio/Horn Acc 10A 6		15 Main Beam O/S 10A	
Body Control unit 5A 7		14 Reverse/Brake Lights 15A	
Body Control Unit/Fuel Level Unit 7.5A 8		13 Indicators/Headlights 15 A	
Rear/Front Fog 15A 9		12 Wipers N/S 10A	
Heated Screen 15A 10		11 Heater O/S 10A	